



INSTRUCTIONS FOR INSTALLATION:

- ◇ When installing the small side vents, it is best to leave the stock screens in. You can remove the one on the front of the hood.
- ◇ Hold **AirVents** up to the area where you will install them and mark and drill the rivet holes using a 3/16" drill bit.
- ◇ Use enclosed rivets to attach **AirVents** to your stock panel.
- ◇ Enjoy your **COOL** sled!

Thank you for your Business!

Tammy or Alan Schoen
BUS: 1-208-587-8584
FAX: 1-208-445-4624

info@2coolairvents.com
www.2coolairvents.com

NOTE: If you get a puncture or tear in your panel, contact us and we can replace the fabric at a nominal cost as long as the frame is in good shape