

Have the Coolest Sled on the Snow!



Alan & Tammy Schoen  
361 SE Sunrise Drive  
Mountain Home, ID 83647

208-587-8584  
www.2coolairvents.com  
schoen311@roadrunner.com

**INSTRUCTIONS FOR INSTALLATION:**



- ◇ Hold **AirVents** up to the area where you will install them and mark and drill the rivet holes using a 3/16" drill bit.
- ◇ Use enclosed rivets to attach **AirVents** to your stock panel.
- ◇ Enjoy your **COOL** sled!

Thank you for your Business!

NOTE: If you get a puncture or tear in your panel, contact us and we can replace the fabric at a nominal cost as long as the frame is in good shape.