



2Cool AirVents

INSTRUCTIONS FOR INSTALLATION:

- ◇ Hold *AirVents* up to the outside of the stock panel on the sled and mark holes.
- ◇ Drill holes in the marked places on the stock panel.
- ◇ It is our recommendation that you grab a holesaw and drill some holes in the area behind the vent so air can flow through the *AirVents* once installed. It is up to you to determine amount of airflow needed for your particular application. If you choose to cut out the entire panel behind the vent, realize that the strength of your panel may be compromised and the vent may not fit as it was intended.
- ◇ Use 3/16" black rivets to attach new *AirVents* to your stock panel.
- ◇ Enjoy your "*COOL*" sled!

Please contact us with Suggestions or Problems!

Tammy or Alan Schoen
1-208-587-8584 or 1-208-590-1786

schoen311@adelphia.net
www.2coolairvents.com

NOTE: If you get a puncture or tear in your panel, contact us and we can replace the fabric at a nominal cost.